

Einrichten vom W-Lan beim ARCH Linux Default Image

Quelle Wifi/Wlan Config

- einloggen als root z.b. ssh root@<pikvm-ip-adresse>
- Filesystem ReadWrite einstellen (rw)
- W-lan Service einschalten „systemctl enable netctl-auto@wlan0.service“
- W-LAN per GUI oder CLI konfigurieren
 - wifi-menu -o #GUI
 - wpa_passphrase wifiname this_is_my_great_and_secure_key_1234567890 #CLI WPA-Key
 - nano /etc/netctl/wlan0-wifiname #CLI Konfigurations file

Login & filesystem RW

```
ssh root@pikvm  
rw
```

GUI

TIPP

The -o makes sure that the WiFi passphrase is stored encrypted.

```
wifi-menu -o
```

From:
<https://waf.logout.de/> - quad.logout.de

Permanent link:
<https://waf.logout.de/pikvm:wlan?rev=1603272369>

Last update: **2020/10/21 09:26**

